

Industrial Sensor Node Lite (ISN Lite) Installation Instructions

Follow these steps to properly mount and connect your device. The instructions cover battery installation, alignment and mounting for optimal accuracy. Ensure each step is completed for correct installation and reliable performance.

Mounting Instructions



1. Battery: Place the batteries in the cover according to the correct polarization direction as shown in the provided image.



2. Cover Assembly: Fit the circuit board with the lower part of the cover, aligning it with the arrow in the image. Tighten the screws to ensure the cover is secure.



3. Alignment & mounting: For best accuracy, mount the unit aligning the X, Y, and Z axes with those of the machine. Use 3M VHB double-sided tape (or equivalent) to install the sensor on the desired surface.